




[ ] IMS(IP Multimedia Subsystem) Emergency Call



**IMS Emergency Call**





< 1> E-CSCF

1 E-CSCF P-CSCF

IMS Emergency Call P-CSCF

IMS Emergency Call E-CSCF가

IMS 가 Emergency Call 가

가 E-CSCF 가 E-CSCF

LRF (Location Routing Function) 가 E-CSCF가 IMS Emergency Call

Emergency Call PSAP(Public Safety Answering Point, Emergency call ) IMS Emergency Call

LRF PSAP LRF

IMS Emergency Call

PSAP P-CSCF E-CSCF IMS Emergency Call

PSAP E-CSCF PSAP 가


PSAP SIP(Session Initiation Protocol) IP Multimedia Network

PSTN(Public Switched Telephone Network)

PSAP PSAP IMS Emergency Call

## IMS Emergency Call

### IMS Emergency Call



< 2> IMS Emergency Call

### IMS Emergency Call

1. UE (User Equipment, 3GPP)가 emergency session
2. UE IMS IMS Emergency Call capability 가
3. UE가 IP-CAN (Bearer-level )
4. UE IP-CAN (IP Capable Network) IMS Emergency Call
5. UE IMS Emergency Call IMS P-CSCF
6. UE IMS Emergency Call 가 가
7. PSAP IMS Emergency Call

E-CSCF IMS Emergency Call IMS 가  
IMS Emergency Call  
가 3 . IMS Emergency Call  
(LG , dhshim@lge.com)